Daily

- 1. Startup and QC all analyzers
- 2. Remove any trash from lab areas
- 3. Wipe down benches with 70% EtOH
- 4. Wipe down keyboards with 70% EtOH
- 5. Top up any sheath tanks (with specified buffer or MilliQ-water)
- 6. Fill or replace any additive cleaning bottles (analyzers)
- 7. Empty waste containers and replace bleach
- 8. Assist users as needed
- 9. Start-up and QC sorter if required
- 10. iLab appointment confirmations
- 11. Update training and sorting calendars

Weekly

- 1. If no appointments startup and QC sorter (MWF)
- 2. Make bulk and additive fluids for Agilent machines
- 3. Inventory lab supplies
- 4. Long decontamination shutdown on Bigfoot sorter

Monthly

- 1. Long clean on Aurora
- 2. Data back-up and maintenance on analyzers
- 3. Data removal on offline analysis computers
- 4. Check eye wash stations
- 5. Autoclave Bigfoot bulk fluid bottles
- 6. Check fluid stability on Agilent analyzers
- 7. Order lab supplies as needed